



Tate
1070



Corner Chair
1070-75


W 42	D 42	H 34	SH 20	AH 27	ISW 27	ISD 27 (in)
W 107	D 107	H 86	SH 51	AH 69	ISW 69	ISD 69 (cm)

(1) 20*20 Throw Pillow




Armless Chair
1070-30

W 30	D 42	H 34	SH 20	ISD 27 (in)
W 76	D 107	H 86	SH 51	ISD 69 (cm)



Armless Sofa
1070-32


W 90	D 42	H 34	SH 20	ISD 27 (in)
W 229	D 107	H 86	SH 51	ISD 69 (cm)



Left / Right Arm Facing Loveseat
1070-65 / 1070-66

W 69	D 42	H 34	SH 20	AH 27	ISW 60	ISD 27 (in)
W 175	D 107	H 86	SH 51	AH 69	ISW 152	ISD 69 (cm)


(1) 20*20 Throw Pillow



Left Arm Facing Right Corner Sofa / Right Arm Facing Left Corner Sofa
1070-53 / 1070-54

W 111	D 42	H 34	SH 20	AH 27	ISW 87	ISD 27 (in)
W 282	D 107	H 86	SH 51	AH 69	ISW 221	ISD 69 (cm)


(2) 20*20 Throw Pillows



Left / Right Arm Facing Sofa
1070-67 / 1070-68

W 99	D 42	H 34	SH 20	AH 27	ISW 90	ISD 27 (in)
W 251	D 107	H 86	SH 51	AH 69	ISW 229	ISD 69 (cm)

(1) 20*20 Throw Pillow



Left / Right Arm Facing Chaise
1070-41 / 1070-42

W 39	D 70	H 34	SH 20	AH 27	ISW 30	ISD 27 (in)
W 99	D 178	H 86	SH 51	AH 69	ISW 76	ISD 69 (cm)

(1) 20*20 Throw Pillow